SPORTCRUISER – N126WK – CHECKLIST

Preflight Exterior

Cockpit

A.R.O.W. documents - On board Controls - Free

Key - Out

Master switch - ON

Instrument switch - ON

Engine instrument switch - ON

Flaps – Fully extended

Fuel gauge – Check level

Strobes - Check

If night – Check lights

All switches - OFF

Canopy - Closed

Left Gear

Tire – Inflated, no bald spots

Wheel chocks - Remove

Brakes - No fluid leaks

Brake pads – Thickness sufficient

Gear leg – Good condition

Left Wing

Flap – Down & secure

Aileron – Free & secure Wing tip - Undamaged

Light fixture - Secure

Tie down – Remove

Fuel vent - Clear

Pitot-static tube – Clear & secure

Wing leading edge - Undamaged

Fuel in tank – Sufficient for flight

Fuel – Test quality

Cowling

Cowlings - Secure

Oil cap - Remove

Prop blades – Good condition

Prop – Turn counterclockwise

to burp

Oil level – Check

Oil cap - Replace, close access door

Air Intakes (5) - Not blocked

Nose Gear

Tire - Inflated, tread

Cotter pins – Check

Gear leg – Good condition

Gas Collator – Check fuel

Right Wing

Fuel – Check quality Fuel in tank – Sufficient for flight

Leading edge - Undamaged

Fuel vent - Clear

Tie down - Remove

Light fixture - Secure

Wing tip - Undamaged

Aileron - Free & correct

Trim tab – Cotter pin secure

Flap – Down & secure

Right Gear

Tire – Inflated, no bald spots Wheel chocks - Remove

Brakes - No fluid leaks

Brake pads – Thickness sufficient

Gear leg - Good condition

Antennas

Comm antenna – Secure Transponder antenna – Attached

ELT antenna - Secure

Empennage

Vertical stabilizer – Undamaged Horizontal stabilizer – Undamaged

Elevator – Free and secure

Trim tab – Cotter pin secure

Rudder – Free movement

Tie-down – Remove

360° Walk around, tie downs and

Airplane – positioned for start

Nose wheel - Straight

Preflight Interior

Passenger Briefing

Seatbelt use • Exit procedure Com use • Motion sickness Look for traffic • LSA waiver Fire extinguisher use

Parking brake – ON, pumped Rudder pedals – Adjusted

Master - ON

Instrument Switches - ON

Strobe lights - ON

If Night: Nav lights - ON

Circuit breakers - IN Carb heat - OFF

Fuel selector – Fullest tank

Insert key - Do not turn

Cold Engine Start

Choke - ON • Throttle - IDLE Fuel pump – ON 5 seconds Check surroundings

Shout - "CLEAR PROP!"

Starter – Engage (Max 5 Seconds)

Choke – OFF • Oil pressure – Green Throttle - 2000 RPM

Avionics - ON • Headset - Check

Hot Engine Start

Throttle – IDLE

Check surroundings

Shout – "Clear Prop!"

Starter – Engage (Max 5 Seconds)

Oil pressure – Green

Throttle – 2000 RPM

Avionics - ON

Headset - Check

Pre-taxi

Flaps – Set for takeoff

Transponder – Alt 1200

GPS - ON • ATIS - Copy

Altimeter – Set and verified

Brakes - Test

Contact ground control

KSMO ATIS 119.15

KSMO Ground 121.90 KSMO Tower 120.10

SOCAL Approach Malibu 125.20

Run-Up

Face into wind

Parking brake – Set, pump

Pitch Trim - Set

Roll Trim – Flush with wing (visually

verify)

Pilot Briefing Positive exchange of controls

Plan for power loss on takeoff

(see "Power Loss on Takeoff")

Route of flight (GPS Set)

Run-Up

Stick & Rudder – Box check

Oil temperature – Above 121° F

Power - 4000 RPM

Ignition left - Check * Ignition right - Check *

(*RPM Max drop 300/Max diff 115)

Carb Heat – Check slight drop

Volts – 12–14 volts Temps and pressures – All green

Power - Idle check

Power - 2000 RPM

Transponder – Set Contact ground control

Holding Short Canopy – Locked and secure

Flaps - Set for takeoff Fuel pump - ON • Landing Lgt - ON

Trim for takeoff • Monitor CHT Contact tower (KSMO 120.10)

WARNING: Avoid prolonged periods of not facing into the wind

SPORTCRUISER – N126WK – CHECKLIST		
Taking the Active Runway	Descent	Emergency Procedures
The following items should be	Power – Set for decent rate	Power Loss in Flight
checked by memory every time	Pitch – Constant airspeed	_
pilots taxi onto a runway.	Carb heat – ON	Airspeed – Best glide: 60 Kts
Check final – Clear	Landing Light – ON within 10 miles	B est Field – Choose, fly
Check canopy – Locked	of an airport	towards, plan approach
Check flaps – Set for takeoff	Go-Around	<u>C</u> hecklist – 7 Up:
Check carb heat – OFF	Power – Full	Throttle – Cracked
Check fuel pump – ON	Pitch for best climb (Vy) – 65 KTS	Choke – OFF
Power Loss on Takeoff	Carb heat – OFF	Fuel Selector – Switch tanks
On Ground	Flaps – Retract in stages	Carb heat – ON
Throttle – Idle	Announce – "Going around, 5PS" Pre-Landing	Fuel pump – ON
Brakes – Apply	Fuel Pump – ON	Master – ON
Flaps – Up	Landing Light - ON	Starter – Engage, if prop
Aircraft – Stop	Carb heat – ON	stopped
Ignition – OFF	Power – 3500	_ ' '
Below 500 Feet AGL	Pitch – Level to slow to Vfe – 75 Kts	<u>D</u> eclare:
Lower nose abruptly – Pitch 60	Flaps – As necessary	Squawk – 7700
Kts	Pitch for approach speed of 65 Kts	Mayday – 121.50 or current
Ignition – OFF	Trim to relieve control pressures	frequency
Fuel pump – OFF	Clear of Runway	E ngine – Shutdown
Flaps – Full	Carb heat – OFF	Fuel selector – OFF
Land straight ahead	Flaps – Up (Set for takeoff	Fuel pump – OFF
Do not attempt to return to	if taxiing back)	Ignition – OFF
Runway	Fuel pump – OFF Landing Light – OFF	F laps – As required
Above 500 Feet AGL	Contact ground control	
Note MSL Altitude	contact ground control	G et Ready
Land on runway or golf course		Seatbelts – Tighten
Climb	Shut Down	Sunglasses, headset –
Power – 5000 – 5500	Switches off Right to Left	Remove
Pitch for airspeed	Power – Idle	Passenger – Secure
Trim – Relieve control pressure	Ignition – OFF (slowly)	Master switch - OFF
Temperatures – Monitor	Hobbs & tach – Record	Warning: A, B, C much more
At 1000 AGL – Fuel pump OFF	Master – OFF	important than D, E, F, G. Fly
Cruise		the Plane first. Always assume
Power – 4400 – 5000		engine will not restart.
Trim – Relieve control pressure	Tie Down/Secure	Electrical Fire
Temperatures and pressures –	Chocks – Replace	Master – OFF
Monitor	Tie downs – Attach	All switches – OFF
Pre-maneuver	Controls – Secure	Cabin heat – OFF
Perform prior to every maneuver.	V Speeds	Air vents – Open
Memorize this checklist.	Vso – 31	Land – As soon as possible
CEDDCA	Vs1 – 37	
C.E.R.R.C.A.	Vr – 50	
Clearing turn(s)	Vx – 55 Vy – 65	Engine Fire
= ::	vy – 65 Vfe – 75	Fuel selector - OFF
Emergency landing area	Va – Low weight (900 lbs) – 70	Throttle – Full Open
Radio – Announce position	Va – Max weight (1320 lbs) – 88	Fuel pump – OFF
Reference point -Airspeed,	Vno – Max cruise – 108	Ignition – OFF, when engine
heading, altitude	Vne – 138	stops
C onfigure A ircraft – Appropriate	Best glide (max weight) – 60	Emergency descent Vne –
for maneuver		Altitude permitting